



PUMP CARE GUIDE

To ensure your pump functions at its best there are a few things you need to do.

Most pumps sold generally have a sponge in the inlet cover. The sponge need to be removed and washed out periodically - at least every 2-3 months or more frequently if there are over hanging trees or plants dropping leaves into the water. At the same time, it's a good idea to take the inlet housing off and check that the impeller has no algae, grit or other particles obstructing it. If your pump doesn't have a sponge, you still need to check the impeller for obstructions.

If you have live plants or fish in your pond/feature, you will need to do this more frequently as the waste load in your pond/feature will be higher. We also supply natural, easy to use products to help break down and remove this waste and keep your pond/feature water clean and clear.

Please retain your invoice and receipt for warranty if needed. Warranty cannot be claimed without the receipt. Please be aware that if you cut the electrical cord your warranty will become null and void.

By following these simple steps your pump will be operating at its best, ensuring your pond/feature will be *Your Own Piece of Serenity* for many years to come.